

Document Name: Kinyoun Stain Job Aid

Distribution:Microbiology Microscopy Manual

Document Number: MIC20131

Date Issued: 17 Jun 2021

Performing the kinyoun stain:

1	SoftMic ordering code is: • STKIN
2	Prepare a slide of the sputum sample and allow to dry
3	 Place the dry slide(s) and 1 AFB QC slide on the staining rack
4	 Completely flood all smears with Kinyoun Carbol-Fuchsin Leave for 4 minutes Using gentle pressure, rinse slides in running tap water Continue to rinse slides until all stain is removed
5	 Completely flood all smears with Decolorizer Leave for 3 to 5 seconds Using gentle pressure, rinse slides in running tap water NOTE: Decolourize smears one-by-one. Do NOT batch
6	 Completely flood all smears with Methylene Blue Leave for 30 seconds Using gentle pressure, rinse slides in running tap water
7	 Place slides in a slide holder and allow to drip dry Stained slides may be placed in the O₂ incubator

NOTE: This is a controlled document for internal use only. Any documents appearing in paper form are not controlled and should be checked against electronic version prior to use.

FILENAME: MIC20131-Kinyoun Stain Job Aid

Print Date: 2 December 2025