

- A. Enter patient ID
- B. Select #1
- C. Gently mix specimen transport tube
- D. Select Main Menu (esc if not there)
- E. Enter User ID and press enter
- F. Click cassette into place and press enter
- G. Pipette 200uL into sample well and press enter
- H. Remove cassette from foil pack and insert into analyzer
- I. Enter cassette lot# and press enter
- J. Express as much liquid as possible by rolling swab against inside of tube.