



University of Washington Medical Center 1959 NE Pacific Street. Seattle, WA 98195 Transfusion Services Laboratory Policies and Procedures Manual	Original Effective Date:	Number: PC-0094.01
	Revision Effective Date:	
TITLE: Preparing RBCs for Intrauterine (IUT) and Neonatal Exchange Transfusions		

PURPOSE:

To define the process for packing and reconstituting red blood cell components (RBC) for intrauterine and neonatal exchange transfusions

PRINCIPLE & CLINICAL SIGNIFICANCE:

Principle

Total blood volume and hemoglobin levels of fetuses, newborns and NICU patients vary based on age, size, and clinical status. The ability to pack RBCs and prepare reconstituted whole blood allows the Transfusion Service laboratory to prepare components especially suited for this patient population.

Clinical Significance

The main indication for intrauterine transfusion (IUT) is the treatment of fetal anemia due to maternal RBC alloimmunization. Exchange transfusion (ET) with reconstituted whole blood is usually indicated for the treatment of severe hemolytic disease of the fetus and the newborn (HDFN) and reduce severe hyperbilirubinemia and maternal alloantibodies present in the neonate. Other clinical situations may require IUT, or ET as determined by the medical provider.

POLICIES:

- **Notify** the Transfusion Service Laboratory (TSL) Medical Director on-call for any IUT or exchange transfusions
- **This is a multistep process.** Please review the Appendix Workflow Overview Diagram for clarification.
- **Selection Requirements for Red Blood Cell Component (RBC)**
 - O negative, leukoreduced
 - <7 days from collection date (older RBCs requires TSL MD approval and initiation of a QI form)
 - NOT irradiated – Irradiation occurs after centrifuging to pack the RBCs
 - Hemoglobin S negative
 - Antigen negative for any maternal antibodies and crossmatch compatible with maternal plasma.

NOTE: Consult with TSL MD if appropriate O negative, antigen negative unit is not in stock prior to ordering from blood supplier

- **Desired Final Hematocrit (HCT) Requirements -**
 - Intrauterine Transfusion: HCT 65 -70%
 - Exchange Transfusion/Reconstituted Whole Blood (RWB): provider to specify final HCT (usually 45%)
 - Send RBC samples to hematology to determine HCT

- **Reconstituted Whole Blood (RWB)** for exchange transfusion
 - RBCs used to manufacture RWB should be packed by centrifugation followed by irradiation prior to reconstitution
 - The following information is required **prior to reconstituting** a packed RBC component. If any of the information is missing from the order, contact the ordering provider to obtain the required information.
 - Date and time of planned transfusion
 - Total volume of RBC to be transfused
 - Desired hematocrit
 - **Selection of Fresh Frozen Plasma for reconstitution**
 - Group AB (Rh type does not matter)
 - Freshly thawed
 - In some situations, a provider may request reconstitution with platelets instead of plasma.
 - **Platelet** requirements:
 - Apheresis in plasma or PAS platelets are acceptable
 - Irradiated or pathogen reduced (PRT)
 - ABO/RH

Neonate	Platelet ABO/Rh
Any ABO and Rh Negative	AB Negative
Any ABO and Rh Positive	AB Positive or AB Negative
 - If a platelet matching the ABO/Rh requirement above is not available, call the TSL MD on-call to ask if a different ABO group is acceptable prior to ordering a group AB platelet from a blood supplier
 - Notify the TSL manager prior to processing for guidance on how to process document and relabel product. SQ does not allow for reconstitution with platelets

SPECIMEN REQUIREMENTS:

NA

REAGENTS/SUPPLIES/EQUIPMENT:

Reagents:	Supplies:	Equipment:
None	<ul style="list-style-type: none"> • Transfer packs • Centrifuge balance discs • Counterweight bags filled with saline or water • Plasma Transfer Set • Hemostats • Scissors • Tubing stripper • Plastic overwrap bags 	<ul style="list-style-type: none"> • Sterile Welder • Plasma Extractor • Tube Sealer • Scale • Refrigerated Centrifuge

QUALITY CONTROL:

Sample of final component is sent to Hematology to determine the final hematocrit

INSTRUCTIONS:

Table of Contents:

- [Selecting and Testing Components Prior to Component Processing](#)
- [Packing RBCs by Centrifugation](#)
- [Relabeling and Irradiating Packed RBC](#)
- [Reconstituting Whole Blood](#)
- [Appendix: Workflow Overview Diagram](#)


Selecting and Testing Components Prior to Component Processing


STEP	ACTION		
1	Notify the TSL MD on-call of orders for an IUT or ET order		
2	If order is for	Then	
	Reconstitution with platelets	Notify a TSL manager to provide guidance for process, documenting and labeling the reconstituted RBC NOTE: SQ does not allow reconstitution with platelets	
	Reconstitution with plasma or IUT	Go to the next step	
3	Select the appropriate red blood cell component <ul style="list-style-type: none"> • O negative RBC, leukoreduced • <7 days from collection date (older RBCs requires TSL MD approval and initiation of a QI form) • Hemoglobin S negative • Antigen negative for any maternal antibodies and crossmatch compatible with maternal plasma NOTE: Consult TSL MD if appropriate O negative, antigen negative unit is not available in stock prior to ordering from blood supplier		
4	Perform crossmatching with maternal sample, and phenotyping of the selected RBC based on maternal antibodies, as required		
5	If transfusion is for	Then	
	Neonate IUT	Go to next step	
	Exchange Transfusion/Reconstituted Whole Blood	Reconstituting with	Select
		Plasma	Frozen AB plasma. Thaw and place in refrigerator until needed
		Platelets	Refer to the requirements specified in the policy section above
6	Discard the segment farthest from the bag retaining the other segment to send to Hematology for a HCT		
7	Label a clean test tube with the unit number		

STEP	ACTION		
8	Remove the remaining segment, cut the tip, and allow the contents to empty into the labeled test tube		
9	Cap the test tube and deliver to Hematology for a STAT hematocrit request a printed report of the results		
10	If	And Hct	Then
	IUT	65-70%	<ul style="list-style-type: none"> No further processing needed Go to SQ Blood Product Entry Add the 'IUT and the HCT as a comment EXAMPLE: IUT HCT = 68%
	IUT	<65%	Go to section Packing RBC by Centrifugation
	Exchange Transfusion	>45%	Go to section Packing RBC by Centrifugation

Packing RBC by Centrifugation


STEP	ACTION		
1	Verify temperature of the centrifuge		
	If internal temperature is	Then	
	Between 1-6°C	Continue to next step	
	>6°C	<ul style="list-style-type: none"> Press the snowflake to precool Set a timer for 30 min. Press stop when centrifuge has precooled for 30 min. Confirm the internal temperature is between 1-6°C 	
		If temperature is	Then
	Between 1-6°C	Go to next step	
	>6°C	Repeat precool	
2	Tare the electronic scale with an empty blood bag then weigh the packed RBC (refer to <i>SOP Scale Operation Entris 2202-1S Balance</i>)		
3	Divide the weight (in grams) by the specific gravity (1.088) to determine the volume (ml) of the packed RBC component (pRBC) Volume of pRBC (mL) = Weight (g) / 1.088 (specific gravity)		
4	Using the HCT obtained from hematology, calculate the volume of anticoagulant to remove to reach the desired HCT and volume of the packed RBC. Note: for IUT calculate the desired HCT = 68% 1) Desired Final RBC Volume (mL) = $\frac{\text{Starting Volume of RBC} \times \text{Starting HCT}}{\text{Desired HCT}}$		

STEP	ACTION
	<p>2) Weight of supernatant to remove (g) = (Starting Volume – Desired Volume) x 1.088</p> <p>EXAMPLE: Request= 68% HCT Starting HCT of RBC = 62.5% Starting Volume of RBC = 311</p> <p>Desired Final RBC Volume (mL) = $\frac{311 \times 62.5}{68} = 286$ mL</p> <p>Weight of supernatant to remove (g) = (311 mL – 286 mL) x 1.088 = 27g</p>
5	<p>Attach a transfer bag to the RBC using a sterile tubing welder, leaving at a minimum 14" of tubing connecting the bags (refer to SOP <i>Sterile Welder Operation, Cleaning & Maintenance SOP</i>)</p> <p>NOTE: Place a plastic clamp on the tubing prior to welding to prevent the RBCs from flowing into the transfer pack</p>
6	<p>Verify the following centrifuge conditions are met and document on the <i>Refrigerated Centrifuge QC Log</i>:</p> <ul style="list-style-type: none"> • Verify internal temperature is within 1-6°C range • RCF = 4200g • Timer = 5 minutes • Deceleration = 6
7	<p>Following SOP <i>Refrigerated Centrifuge Operation and Maintenance</i> centrifuge the RBC to separate the red blood cells from the plasma and additives</p> <p>NOTE: It may be necessary to use a transfer bag filled with saline as a balance instead of weights</p>
8	<p>Carefully remove the unit from the centrifuge without disturbing the contents upon completion of the cycle</p>
9	<p>Insert the packed RBC, with the label facing the back, into the plasma extractor</p>
10	<p>Place the transfer bag on the scale and tare the scale</p>
11	<ul style="list-style-type: none"> • Note the time • Release the plasma extractor plate handle and unclamp the tubing between the RBC and the transfer bag to express the supernatant into the transfer pack until the weight calculated in step 4 above is reached <p>NOTE: The time noted is entered during the Blood Component Processing step in the LIS to calculate the new expiration date.</p>  <p>The screenshot shows a software interface titled "Blood Component Prep". It has two main sections: "Component Prep Function" and "Date/Time". Under "Component Prep Function", there is a dropdown menu set to "Component Prep Function", a "Value" field with a green arrow icon, and a "Code" field. Under "Date/Time", there are "Date" and "Time" fields, both with green arrow icons. The "Time" field is circled in red.</p>

STEP	ACTION									
8	<ul style="list-style-type: none"> Clamp the tubing with the plastic clip Press down and latch the plasma extractor plate handle in the open position 									
9	Strip the tubing towards the transfer pack and place a hemostat to prevent plasma from running back into the tubing									
10	Heat seal the tubing between the bags close to the transfer pack									
11	Remove and discard the transfer pack									
12	Strip and mix the tubing 4 times <ul style="list-style-type: none"> Strip the length of tubing attached to the RBC back into the component Without releasing the stripper, mix the contents of the RBC Release and allow RBCs to flow back into the tubing 									
13	Use the heat sealer to make two segments long enough to provide a 1 mL sample, approximately 3-4 inches long segments EXAMPLE: 									
14	Discard the segment farthest from the bag retaining the other segment to send to Hematology for a HCT									
15	Label a clean test tube with the unit number									
16	Remove the remaining segment, cut the tip, and allow the contents to empty into the labeled test tube									
17	<ul style="list-style-type: none"> Cap the test tube and deliver to Hematology for a STAT hematocrit request a printed report of the results 									
18	Tare the scale with an empty blood bag then weigh the packed RBC (refer to SOP <i>Scale Operation Entris 2202-1S Balance</i>)									
19	Divide the weight (in grams) by the specific gravity (1.088) to determine the volume (ml) of the packed RBC component (pRBC) Volume of pRBC (mL) = Weight (g) / 1.088 (specific gravity)									
20	Obtain the printed hematocrit report									
21	If transfusion is for	Then								
	Neonate IUT	<table border="1"> <thead> <tr> <th>If HCT result is:</th> <th>Then</th> </tr> </thead> <tbody> <tr> <td>Between 65-70%</td> <td>Go to next step</td> </tr> <tr> <td><65%</td> <td>Repack the RBC</td> </tr> <tr> <td>>70%</td> <td>Notify the TSL MD on-call to contact the provider to determine if the HCT is acceptable</td> </tr> </tbody> </table>	If HCT result is:	Then	Between 65-70%	Go to next step	<65%	Repack the RBC	>70%	Notify the TSL MD on-call to contact the provider to determine if the HCT is acceptable
		If HCT result is:	Then							
		Between 65-70%	Go to next step							
<65%	Repack the RBC									
>70%	Notify the TSL MD on-call to contact the provider to determine if the HCT is acceptable									
Exchange Transfusion/	Go to next step									

STEP	ACTION
	Reconstituted Whole Blood
21	Go to section Relabeling and Irradiating Packed RBC


Relabeling and Irradiating Packed RBC

STEP	ACTION						
1	Open the SQ Blood Component Preparation Module (BCP)						
2	<ul style="list-style-type: none"> Follow SOP Blood Component Preparation to complete documentation and relabeling of the packed (volume reduced) component Enter the time noted in step 7 of section Packing RBCs by Centrifugation in the time field 						
3	IRRADIATE the new component following SOP Irradiation of Blood Components then follow SOP Blood Component Preparation to modify in SQ and relabel as irradiated						
4	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr style="background-color: #cccccc;"> <th style="width: 30%;">If transfusion is for</th> <th>Then</th> </tr> </thead> <tbody> <tr> <td>Intrauterine Transfusion</td> <td> <ul style="list-style-type: none"> Go to next step </td> </tr> <tr> <td>Exchange Transfusion/ Reconstituted Whole Blood</td> <td> <ul style="list-style-type: none"> Go to section Reconstituting Whole Blood </td> </tr> </tbody> </table>	If transfusion is for	Then	Intrauterine Transfusion	<ul style="list-style-type: none"> Go to next step 	Exchange Transfusion/ Reconstituted Whole Blood	<ul style="list-style-type: none"> Go to section Reconstituting Whole Blood
If transfusion is for	Then						
Intrauterine Transfusion	<ul style="list-style-type: none"> Go to next step 						
Exchange Transfusion/ Reconstituted Whole Blood	<ul style="list-style-type: none"> Go to section Reconstituting Whole Blood 						
5	<ul style="list-style-type: none"> Go to SQ Blood Product Entry Add the 'IUT and the HCT as a comment using 'Modify Unit...' <p style="margin-left: 20px;">EXAMPLE: IUT HCT = 70.5</p>						
6	Notify the patient care area when the reconstituted RBC is available						

Reconstituting Whole Blood

STEP	ACTION
1	Verify the RBC is packed, irradiated and relabeled accordingly per previous sections: Packing RBCs by Centrifugation and Relabeling and Irradiating Packed RBC

STEP	ACTION						
2	<p>Calculate the amount of pRBC and thawed FFP needed to make the requested volume of reconstituted whole blood (RWB) using the following equations</p> <p>pRBC volume (mL) needed = $\frac{\text{RWB Volume (mL) requested} \times \text{Desired HCT (40 - 50\% NICU)}}{\text{HCT of RBC unit}}$</p> <p>FFP volume (mL) needed = $\text{RWB Volume (mL) requested} - \text{pRBC volume (mL) needed (from above equation)}$</p> <p>EXAMPLE: The provider request 450 ml of reconstituted whole blood with a hematocrit of 45%. The hematocrit of the pRBC is 68%.</p> <p>pRBC volume (mL) needed = $\frac{450 \times 45}{68} = 297 \text{ mL}$</p> <p>FFP volume (mL) needed = $450 - 297 = 153 \text{ mL}$</p> <p>NOTE: 1 gm of plasma can be considered equivalent to 1 ml of plasma and does not require adjustment due to the specific gravity</p>						
3	<table border="1"> <thead> <tr> <th data-bbox="315 989 732 1039">If the prepared pRBC is</th> <th data-bbox="732 989 1459 1039">Then:</th> </tr> </thead> <tbody> <tr> <td data-bbox="315 1039 732 1207">Adequate to complete processing</td> <td data-bbox="732 1039 1459 1207">Place the required amount of RBC in bag according to the SOP <i>Dividing Blood Components</i> according to the SOP <i>Dividing Blood Components</i> NOTE: Be sure the bag will hold the entire final volume prior to starting</td> </tr> <tr> <td data-bbox="315 1207 732 1276">Inadequate to complete processing</td> <td data-bbox="732 1207 1459 1276">Consult with the TSL MD concerning the shortage and need for an addition pRBC</td> </tr> </tbody> </table>	If the prepared pRBC is	Then:	Adequate to complete processing	Place the required amount of RBC in bag according to the SOP <i>Dividing Blood Components</i> according to the SOP <i>Dividing Blood Components</i> NOTE: Be sure the bag will hold the entire final volume prior to starting	Inadequate to complete processing	Consult with the TSL MD concerning the shortage and need for an addition pRBC
If the prepared pRBC is	Then:						
Adequate to complete processing	Place the required amount of RBC in bag according to the SOP <i>Dividing Blood Components</i> according to the SOP <i>Dividing Blood Components</i> NOTE: Be sure the bag will hold the entire final volume prior to starting						
Inadequate to complete processing	Consult with the TSL MD concerning the shortage and need for an addition pRBC						
4	Select a thawed Group AB plasma with sufficient volume to reconstitute the RBC						
5	Contact the patient care area to verify timing of the transfusion prior to continuing to the next step						
6	Obtain a plasma transfer set and close the clamp on the tubing						
7	Insert one spike into the plasma bag and the other into the RBC unit using aseptic technique						
8	Place the RBC unit on the scale and TARE the scale to 0						
9	Elevate the FFP, open the clamp and allow the volume of plasma required to flow into the RBC bag						
10	Close the clamp when the desired volume is reached						
11	<p>Heat seal the tubing leaving approximately 5" of tubing on the transfer pack incase reattachment is necessary (refer to SOP <i>Tube Sealer: Operation and Cleaning</i>)</p> <p>NOTE: Having adequate tubing on the RBC bag ensures an accurate HCT measure</p>						

STEP	ACTION								
12	Strip and mix the tubing 4 times <ul style="list-style-type: none"> Strip the length of tubing attached to the RBC back into the component Without releasing the stripper, mix the contents of the RBC Release and allow RBCs to flow back into the tubing 								
13	Use the heat sealer to make two segments long enough to provide a 1 mL sample, approximately 3-4 inches-long segments EXAMPLE: 								
14	Discard the segment farthest from the bag NOTE: The remaining 3-4 inches long segment will be used to verify the hematocrit of the volume reduced unit								
15	Label a test tube with the unit number								
16	Remove the remaining segment, cut the tip, and allow the contents to empty into the labeled test tube								
17	<ul style="list-style-type: none"> Cap the test tube and deliver to Hematology for a STAT hematocrit Obtain a printed report of the results 								
18	<table border="1"> <thead> <tr> <th>If HCT</th> <th>Then</th> </tr> </thead> <tbody> <tr> <td>= HCT ordered</td> <td>Proceed to modification in BBLIS</td> </tr> <tr> <td>< HCT ordered</td> <td> <ul style="list-style-type: none"> Verify calculations are correct Determine the volume of plasma to remove Pack the RWB component according to section Packing RBCs by Centrifugation Remove the excess plasma </td> </tr> <tr> <td>> HCT ordered</td> <td> <ul style="list-style-type: none"> Recheck calculations Determine the volume of plasma to add Add the additional plasma </td> </tr> </tbody> </table>	If HCT	Then	= HCT ordered	Proceed to modification in BBLIS	< HCT ordered	<ul style="list-style-type: none"> Verify calculations are correct Determine the volume of plasma to remove Pack the RWB component according to section Packing RBCs by Centrifugation Remove the excess plasma 	> HCT ordered	<ul style="list-style-type: none"> Recheck calculations Determine the volume of plasma to add Add the additional plasma
	If HCT	Then							
	= HCT ordered	Proceed to modification in BBLIS							
	< HCT ordered	<ul style="list-style-type: none"> Verify calculations are correct Determine the volume of plasma to remove Pack the RWB component according to section Packing RBCs by Centrifugation Remove the excess plasma 							
> HCT ordered	<ul style="list-style-type: none"> Recheck calculations Determine the volume of plasma to add Add the additional plasma 								
19	Follow SOP Blood Component Preparation to complete documentation and relabeling of the reconstituted whole blood component								
20	<ul style="list-style-type: none"> Go to SQ Blood Product Entry Add the HCT as a comment using 'Modify Unit to EXAMPLE: HCT = 45								
21	Notify the patient care area when the component is available								

CALCULATIONS/INTERPRETATIONS/RESULTS REPORTING/NORMAL VALUES/CRITICAL VALUES

NA

CALIBRATION:

NA

PROCEDURE NOTES AND LIMITATIONS:

- If a washed RWB is requested, TSL MD consultation and approval with proper documentation is required
- Modification to irradiated must occur after reduced volume modification in SQ and before modification to reconstituted.
- Following exchange transfusion, plasma bilirubin levels may increase due to re-equilibration of the plasma with the extravascular tissues. Repeat exchange transfusions may be required

REFERENCES:

AABB Technical Manual, 18th Ed., Bethesda, MD; AABB, 2014

AABB Standards for Blood Banks and Transfusion Services, Bethesda, MD, Current edition.

RELATED DOCUMENTS:

Form Component Prep Downtime Log

Form Refrigerated Centrifuge QC Log

SOP Irradiating Blood Component

SOP Blood Component Preparation

SOP Helmer Plasma Thawer Operation and Maintenance

SOP Refrigerated Centrifuge Operation and Maintenance

SOP Sterile Welder Operation and Maintenance

SOP Tube Sealer Operation and Maintenance

SOP Scale Operation & Maintenance: Entris 2202-1S Balance

UWMC SOP Approval:

**UWMC CLIA
Medical Director**

Mark H. Wener, MD Date

**Transfusion
Service Manager**

Nina Sen Date

**Compliance
Analyst**

Christine Clark Date


**Transfusion
Service
Medical Director**

Monica Pagano, MD Date

UWMC Biennial Review:

Date


Date



APPENDIX:

Workflow Overview Diagram

Intrauterine Transfusion



Neonatal Exchange Transfusion – Reconstituted RBC

